



Instructions:

Print double sided on heavy weight cardboard stock

Cut along dotted outside line on reverse

Score along dotted inside lines

Fold along dotted inside lines as per diagram to left, with white on inside, and black side out

Use rubber band to attach reflector to flash unit

When not in use, base of reflector folds nicely up to top part, laying flat

Sony

